

Filling Process for Computrol system

1. Remove nozzle from dispenser and connect nozzle onto the receptacle, insure that it is secure and sealed correctly.
2. Go to card reader and swipe the key fob,
3. Enter the pin and choose the pump number.
4. When the display shows "enable pump" turn on dispenser.
5. The pump will then give a 4 second burst of gas for a volume sample and then proceed to fill vehicle.
6. Once filling has finished dispenser will "beep."
7. Then turn dispenser to off position.
8. Remove nozzle from receptacle and holster in dispenser.