

Hamburg Complex
-Hamburg Refrigeration-
HROM

Revised February 09, 1996

1.00 HROM TABLE OF CONTENTS

1.0 GENERAL

1.01 REFRIGERATION UNIT

- 1.01.01 Overview
- 1.01.02 Residue Gas System Components
- 1.01.03 Residue Gas System Start-Up

1.02 REFRIGERATION UNIT USD SYSTEM

- 1.02.01 Overview

1.03 REFRIGERATION INLET SEPARATOR

- 1.03.01 Inlet Separator Overview
- 1.03.02 Inlet Separator Components and Operation
- 1.03.03 Inlet Separator Alarms and Shutdowns

List of Graphics

- HR1032 Inlet Separator V-2100

1.04 REFRIGERATION EXCHANGERS

- 1.04.01 Refrigeration Exchangers
- 1.04.02 Refrigeration Exchangers Equipment Data
- 1.04.03 Refrigeration Exchangers Start-Up
- 1.04.04 Refrigeration Exchangers Shutdown
- 1.04.05 Refrigeration Exchangers Troubleshooting
- 1.04.06 Routine Activities

1.05 LOW TEMPERATURE SEPARATOR

- 1.05.01 Low Temperature Separator Overview
- 1.05.02 Low Temperature Separator Operation
- 1.05.03 Low Temperature Separator Start-Up
- 1.05.04 Low Temperature Separator Alarms and Shutdowns

1.06 BYPASS TO MAIN PLANT

- 1.06.01 Overview

1.07 GAS AND FIRE DETECTION SYSTEMS

- 1.07.01 Fire Detection System
- 1.07.02 Major Components of Fire Detection System
- 1.07.03 Combustible Gas Detection System
- 1.07.04 Major Components of Combustible Gas Detection System

2.0 GAS COMPRESSION

2.01 GAS COMPRESSION SYSTEMS

2.01.01 Gas Compressor Function

2.01.02 Flow Control

List of Graphics

HR2011 Sales Gas Compressor and Overhead Recompressor

2.02 SALES GAS COMPRESSOR

2.02.01 Sales Gas Compressor Control System

2.02.02 Sales Gas Compressor Start-Up

2.02.03 Sales Gas Compressor Shutdown

2.03 SALES GAS AFTERCOOLER

2.03.01 Sales Gas Aftercooler

2.03.02 Components and Operation

2.03.03 Preparation of Aerial Coolers for Maintenance

2.03.04 Troubleshooting Aerial Coolers and Condensers

2.04 STABILIZER RECOMPRESSOR

2.04.01 Stabilizer Overhead Gas

2.04.02 Stabilizer Recompressor Control System

2.04.03 Stabilizer Recompressor Start-Up

2.04.04 Stabilizer Recompressor Shutdown

2.05 OVERHEAD AFTERCOOLER

2.05.01 Overhead Aftercooler

2.05.02 Components and Operation

2.05.03 Preparation of Aerial Coolers for Maintenance

2.05.04 Troubleshooting Aerial Cooler and Condensers

2.06 COMPRESSOR UTILITIES

2.06.01 Compressor Lube Oil

2.06.02 Compressor Jacket Water

2.06.03 Compressor Utility Shutdowns

2.06.04 Compressor Utility Alarms

List of Graphics

HR2061 Compressor Utility Systems

3.0 GLYCOL INJECTION SYSTEM

3.01 GLYCOL INJECTION SYSTEM

3.01.01 Overview

3.01.02 Glycol Unit Components

3.01.03 Glycol Injection Nozzle Operation

List of Graphics

HR3011 Glycol Injection Nozzle

HR3012 Glycol Regeneration System

3.02 GLYCOL SYSTEM

3.02.01 Glycol Unit Start-Up

3.02.02 Glycol Unit Shutdown

3.02.03 Glycol Unit Operation

- 3.02.04 Glycol Unit Routine Activities
- 3.02.05 Glycol Unit Troubleshooting

3.03 GLYCOL REBOILER

- 3.03.01 Overview
- 3.03.02 Glycol Reboiler System components
- 3.03.03 Glycol Reboiler Start-Up
- List of Graphics**
- HR3031 Basic Heater Controls

4.0 PROPANE REFRIGERATION SYSTEM

4.01 REFRIGERATION SYSTEM

- 4.01.01 Overview
- 4.01.02 Refrigeration System Components
- 4.01.03 Refrigeration System Operating Parameters
- 4.04.04 Refrigeration System Equipment Data
- 4.01.05 Refrigeration System Alarms And Shutdowns
- 4.01.06 Refrigeration System Troubleshooting
- 4.01.07 Refrigeration System Start-Up
- 4.01.08 Refrigeration System Shutdown
- 4.01.09 Routine Activities

List of Graphics

- HR4011 Dehydration/Refrigeration System

4.02 PROPANE CHILLER & SUCTION SCRUBBER

- 4.02.01 Overview
- 4.02.02 System Components
- 4.02.03 Propane Chiller and Suction Scrubber Routine Activity
- 4.02.04 Propane Chiller and Suction Scrubber Alarms and Shutdowns

4.03 PROPANE REFRIGERATION COMPRESSOR

- 4.03.01 Overview
- 4.03.02 System Components
- 4.03.03 Propane Compressor Operation
- 4.03.04 Propane Compressor Alarms and Shutdowns

4.04 PROPANE CONDENSER

- 4.04.01 Overview
- 4.04.02 System Components
- 4.04.03 Routine Activity
- 4.04.04 Start-Up
- 4.04.05 Shutdown
- 4.04.06 Troubleshooting

4.05 PROPANE ACCUMULATOR

- 4.05.01 Overview
- 4.05.02 System Components
- 4.05.03 Propane Accumulator Alarms

4.06 PROPANE COMPRESSOR UTILITIES

- 4.06.01 Lube Oil System Components

- 4.06.02 Glycol System Components
- 4.06.03 Lube Oil System Start-Up
- 4.06.04 Glycol System Start-Up

List of Graphics

- HR4061 Propane Compressor Utilities

5.0 CONDENSATE SYSTEM**5.01 CONDENSATE STABILIZATION SYSTEM & FLOWS**

- 5.01.01 Overview
- 5.01.02 System Components

List of Graphics

- HR5011 Condensate Stabilization System

5.02 STABILIZER FEED DRUM

- 5.02.01 Operation
- 5.02.02 Feed Drum Operating Parameters

List of Graphics

- HR5021 Stabilizer Feed Drum

5.03 STABILIZER REBOILER

- 5.03.01 Overview
- 5.03.02 Unit Components
- 5.03.03 Condensate Stabilizer and Reboiler Operation
- 5.03.04 Condensate Stabilizer Start-Up
- 5.03.05 Condensate Stabilizer Shutdown
- 5.03.06 Condensate Stabilizer Routine Activity
- 5.03.07 Condensate Stabilizer Operating Parameters
- 5.03.08 Condensate Stabilizer Alarms and Shutdowns
- 5.03.09 Troubleshoot Condensate Stabilizer and Reboiler

List of Graphics

- HR5031 C-2100 Condensate Stabilizer
- HR5032 C-2100 Internals

5.04 STABILIZER O/H CONDENSER & REFLUX PUMPS

- 5.04.01 Unit Components
- 5.04.02 Stabilizer Overhead System Operation
- 5.04.03 Stabilizer Overhead System Operating Parameters
- 5.04.04 Stabilizer Overhead System Equipment Data
- 5.04.05 Stabilizer Overhead System Alarms and Shutdowns

5.05 CONDENSATE SYSTEM EXCHANGERS

- 5.05.01 Overview
- 5.05.02 Condensate System Exchangers Equipment Data
- 5.05.03 Condensate System Exchangers Operation

6.0 HOT OIL HEATING SYSTEM**6.01 HOT OIL SYSTEM**

- 6.01.01 Hot Oil System Overview
- 6.01.02 Hot Oil System Components

List of Graphics

- HR6011 Heat Medium Oil System

6.02 HOT OIL HEATER F-2500

- 6.02.01 Hot Oil Heater Operation
- 6.02.02 Hot Oil Heater Start-Up
- 6.02.03 Hot Oil Heater Shutdown
- 6.02.04 Hot Oil Heater Routine Activity
- 6.02.05 Hot Oil System Operating Parameters
- 6.02.06 Hot Oil Heater Equipment Data
- 6.02.7 Hot Oil System Alarms and Shutdowns
- 6.02.08 Troubleshoot Hot Oil System

List of Graphics

- HR6021 Hot Oil Heater Controls
- HR6022 Simple Vertical Cylindrical Direct Fired Heater
- HR6023 Thermal Efficiency of a Direct Fired Heater

6.03 HOT OIL PUMP

- 6.03.01 Hot Oil Pump Operation
- 6.03.02 Hot Oil Pump Routine Activity
- 6.03.03 Hot Oil Pump Equipment Data

6.04 HOT OIL SURGE TANK

- 6.04.01 Hot Oil Surge Tank Operation
- 6.04.02 Hot Oil Surge Tank Routine Activity
- 6.04.03 Hot Oil Surge Tank Equipment Data

7.0 GLYCOL HEATING SYSTEM**7.01 GLYCOL HEATING SYSTEM**

- 7.01.01 Glycol/Water System Operation
- 7.01.02 Prestart, Start-Up, And Shutdown Glycol/Water System
- 7.01.03 Glycol/Water System Routine Activities
- 7.01.04 Glycol/Water System Operating Parameters
- 7.01.05 Glycol/Water System Equipment Data
- 7.01.06 Glycol/Water System Alarms And Shutdowns
- 7.01.07 Glycol/Water System Troubleshooting

7.02 HEATING GLYCOL EXPANSION TANK

- 7.02.01 Overview
- 7.02.02 Heating Glycol Expansion Tank Operation
- 7.02.03 Heating Glycol Expansion Tank Alarms and Shutdowns